

FILTER CHANGE GUIDE

Frequency is subject to change during busy holiday and event periods

orders@shepherdfilters.co.nz

0800 425 449

www.shepherdfilters.com

LEAVING FILTERS TOO LONG RESTRICTS AIRFLOW, AND INCREASES CLEANING & FIRE RISK!
TURN OFF ALL COOKING EQUIPMENT AND ALLOW TO COOL DOWN BEFORE REMOVING FILTERS



Sharp Objects / Surfaces

GLOVES ARE ADVISABLE WHEN HANDLING FRAMES



Hot Surfaces / Oil



ABOVE FRYER / COMBI ETC.

ABOVE GRILL / HOTPLATE ETC.



RIGHT SIDE UP



WRONG SIDE UP

NO GREY STREAKS = TIME TO CHANGE

**ALWAYS PLACE WOOL FILTER MEDIA ON THE SIDE FEATURING THE MESH
& ENSURE BAFFLES RUN VERTICALLY (UP & DOWN) ON RE-INSTALLATION**