

FILTER CHANGE GUIDE

www.shepherdfilters.com

Frequency is subject to change during busy holiday and event periods

LEAVING FILTERS TOO LONG RESTRICTS AIRFLOW, AND INCREASES CLEANING & FIRE RISK! TURN OFF ALL COOKING EQUIPMENT AND ALLOW TO COOL DOWN BEFORE REMOVING FILTERS

Sharp Objects / Surfaces

GLOVES ARE ADVISABLE WHEN HANDLING FRAMES

















ABOVE FRYER/COMBI ETC.

ABOVE GRILL/HOTPLATE ETC.

RIGHT SIDE UP

WRONG SIDE UP

NO GREY STREAKS = TIME TO CHANGE

ALWAYS PLACE WOOL FILTER MEDIA ON THE SIDE FEATURING THE MESH & ENSURE BAFFLES RUN VERTICALLY (UP & DOWN) ON RE-INSTALLATION



